

REPLACEMENT PADS 替換布

AD51000 DIRT DEVIL WET SCRUBBING PAD 濕用微纖抹布

Assembly 裝配

- Attach mop pad.

安裝抹布

- Flexible members on the side of mop head fit into pockets found on the top of surface of the mop pad.

從拖把頭兩端套入微纖抹布頂部的口袋中。

Operation 操作

- Fill bottle with cleaning solution.

把清水及清潔液倒入水瓶中。

- Remove bottle from product by grasping by the sides of bottle, twisting slightly clockwise and at the same time, firmly pulling upwards along the product handle.

抓住水瓶的兩邊，順時針輕輕旋轉，然後向手柄方向提起來移除水瓶。

- With bottom cap of bottle fully secure, fill bottle from top by grasping edge of top cap and pulling upward away from bottle. Pour solution into exposed opening.

抓住水瓶蓋頂，向上打開蓋子，然後沿水瓶邊倒下清水及清潔液。

- After bottle is full, close top cap by pressing firmly down until cap is fully sealed.

當水瓶裝滿後，從蓋頂用力壓下直至蓋子完全關上。

- Replace bottle into product by firmly press-

ing bottle back down onto product until fully seated.

蓋頂向下，用力壓下直至水瓶牢牢固定在產品上。

- Squeeze trigger to operate product and release cleaning solution. Repeat as required for additional solution.

拉動手制以噴出清水及清潔液。如有需要，可重覆拉動手制獲得更多清潔液。

Care 注意

- Machine wash microfiber mop pads using warm water. DO NOT USE BLEACH OR FABRIC SOFTENER.

產品上的微纖抹布請使用溫水清洗。切勿使用漂白劑或軟化劑。

- Lay mop pad flat to dry.

請平放微纖抹布來進行風乾。

- Mop pad should be completely dry before placing back onto mop head. (approximately 24 hours)

微纖抹布放回拖把前，請需保持完全乾燥。

- After use, empty the bottle. Do not leave the detergent for 1 to 2 days. Please run warm water through the spray mop regularly to clean the residue leaving behind.

使用完後，請清空水瓶。不要把清潔液留於水瓶中。請定期使用溫水來清潔殘留的清潔液。